Risk Assessment For

TS9 5NZ

AR Entertainment's Mount Pleasant Way Stokesley Business Park Stokesley North Yorkshire ASSESSMENT UNDERTAKEN

Date: 29-Mar-17
Signed: R D Booth
Equipment Laser Quest

ASSESSMENT REVIEW DATE:

1st: Sept 2017 2nd: Mar 2018 3rd: Sept 2018 4th: Mar 2019

LIST OF SIGNIFICANT HAZARDS GROUPS AT RISK EXISTING CONTROLS covered by information held

Blower/Power Failure Participants Operators are instructed to open the zip & get all participants out immediately

Overloading Participants Operators are instructed to allow a maximum of 10 similar sized players at any time.

Fire Participants Operators to site inflatable away from naked flames and forbid

Crowd/Operator smoking in and around the inflatable

Inflatable tipping over Participants When on grass the inflatable is always pegged, if on concrete adequate

Crowd sandbags are used to prevent movement

If the operator deems it unsafe to operate due to severe wind speeds

the inflatable should not be inflated

Electric shock Operator Electrical units are visually inspected for obvious faults, fused Ext. cables

are used and equipment is P.A.T. tested once a year

Participants Colliding Participants No running inside the inflatable & if inside ensure lights are on to provide sufficient light

Excessive Wind Participants On Grass Check type of soil type under grass - clay has a lot stronger hold than sand

Securely double peg all anchor points into the ground.

On Hard Standing All supplied weights to be used and anchor to fixed objects if required.

If wind speed exceeds 35km/h on windometer or if pegs start to move in the ground or weights start to move when in use, immediately evacuate & deflate by having power connections at the front for fast deflation until wind has dropped and

operator deems appropriate to re-start.

Alien Members of Public Ensure securely pegged/weighted to the ground. If excessive wind on setting up,

the alien is to be not used. Keep power connections to the front so power can be

stopped if required.

Laser Quest

Safety Data Sheet

Equipment Required:	No Req	In Van	
Lap top	1		
2 x Inflatables & Spare Zip	2 + 1		
2 x 1.5W Electric Blowers	2		
Ext Leads, Converters and Splitter			
Generator			
Crash Mat for entrance	1		
26 Pegs and Hammer / sand bags			
6 Lights* & Torch			
Repair Kit inc. 3-6 Tie raps*	1		
Barrow + Patch diagram			
Groundsheet			
Map & Key & First aid kit	1+1+1		
Guns & Spare Batteries & Whistle	12 + 2 + 1		
Posts & Bunting or Riot Fence & Stakes			
Table + Tablecloth for guns	1		
Loading checked by:			
Return loading checked by:	Event Ma	Event Manager	

Safety Brief

1. No running around the inflatable.

- 2. If for any reason a participant wants to come out, tell them too bang on the entrance zip.
- 3. Keep guns below head height.
- 4. When dark, instruct participants to heed caution in darker areas.
- 5. If the whistle is blown before the end of the game, everyone MUST out immediately.

Assembly Instruction:

- 1. Check ground for sharp protruding objects & clear or find alternative site.
- 2. Lay groundsheet down on required area
- 3. Unroll main inflatable attach 1.5w blower to 1 flange, close other tube, back & front zip
- 4. Inflate & anchor inflatable using either pegs or sandbags
- 5. Once fully inflated & securely anchored deflate & position the Alien
- 6. Close all 4 zips on the base of each foot, Inflate & securely anchor
- 7. Re-inflate the main chamber & ensure the alien is in a central position
- 8. Exhaust on generator to always be at a safe distance from blowers
- 9. Guns & crash mat at the entrance for the participants.
- 10. When dark, place a floodlight at each window to shine into the inflatable, and hang third light from back zip.

Operator Instructions:

- 1. Maximum of 10 participants at any time, of similar age, size & stature
- 2. No Shoes, food, drinks, chewing gum, glasses, jewellery or badges allowed in,
- 3. No Party Poppers, silly string or streamers to be used in or near the inflatable.
- 4. No pets, toys, or sharp instruments allowed in or near the inflatable.
- 5. Ensure that users are not pushing, colliding, fighting or behaving in a manner likely to injure or cause distress to others.
- 6. If the inflatable is not being used for part of the day, please switch off & deflate
- 7. Ensure zip entrance is closed when participants are not entering or leaving.
- 8. No Participants with a history of back, neck problems or heart complaint to enter
- $9.\ \mbox{No}$ participants who are feeling unwell or suffering the effects of alcohol or drugs.
- 10. Do not allow anyone to be one the inflatable during inflation or deflation
- 11. Ensure the area around the inflatable is completely clear
- 12. If power fails ensure all particiannts exit the inflatable immediately
- 13. When starting a game, mobilise an extra gun and keep in reserve with master gun in case of battery failure.

I am fully trained and confident in operating the Laser Quest,	and understand the risk assessments,	assembly instructions and	operating instructions
and any other safety procedures related to the Laser Quest.			

Signed:	Date:	Event Manager/Trainer:
Print Name:		Print Name:

Laser Quest Set up

Laptop Password: Snappy Icombat engine username: ARents password: snappy123

Switch on Laptop and load iCombat Engine (top left of screen) . When the next window appears, click LAUNCH. Switch on Guns .

On next screen click 'play'.

To play Laser Quest click on "Last man standing"

Guns will be on a white back ground saying "ready". if back ground is in red and saying "offline" replace batteries and switch back on

When all guns are 'Ready' click on "duplicate" bottom left of screen then when reloaded click "Load" bottom right screen When the green bar is full screen will change to the game screen.

To start game press"play" button on the right and it will count down 5 sec and game will start.

End of game after taking game scores press the "back" button to restart next game next screen press "duplicate" then "load"